



IP Office

T7000 Telephone User Guide

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

For full support, please see the complete document, Avaya Support Notices for Hardware Documentation, document number 03–600759.

For full support, please see the complete document, Avaya Support Notices for Software Documentation, document number 03–600758.

To locate this document on our website, simply go to <http://www.avaya.com/support> and search for the document number in the search box.

Documentation disclaimer

“Documentation” means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its hardware and Software (“Product(s)”). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support website: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya Channel Partner outside of the United States and Canada, the warranty is provided to you by said Avaya Channel Partner and not by Avaya. “Software” means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products or pre-installed on hardware products, and any upgrades, updates, bug fixes, or modified versions.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO](http://SUPPORT.AVAYA.COM/LICENSEINFO) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED AVAYA CHANNEL PARTNER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS “YOU” AND “END USER”), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE (“AVAYA”).

Avaya grants you a license within the scope of the license types described below, with the exception of Heritage Nortel Software, for which the scope of the license is detailed below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to you. “Designated Processor” means a single stand-alone computing device. “Server” means a Designated Processor that hosts a software application to be accessed by multiple users.

License type(s)

Designated System(s) License (DS). End User may install and use each copy of the Software only on a number of Designated Processors up to the number indicated in the order. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A “Unit” means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software. Units may be linked to a specific, identified Server.

Database License (DL). End User may install and use each copy of the Software on one Server or on multiple Servers provided that each of the Servers on which the Software is installed communicates with no more than a single instance of the same database.

CPU License (CP). End User may install and use each copy of the Software on a number of Servers up to the number indicated in the order provided that the performance capacity of the Server(s) does not exceed the performance capacity specified for the Software. End User may not reinstall or operate the Software on Server(s) with a larger performance capacity without Avaya's prior consent and payment of an upgrade fee.

Named User License (NU). You may: (i) install and use the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use the Software on a Server so long as only authorized Named Users access and use the Software. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Shrinkwrap License (SR). You may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License").

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software currently available for license from Avaya is the software contained within the list of Heritage Nortel Products located at <http://support.avaya.com/LicenseInfo> under the link "Heritage Nortel Products". For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or (in the event the applicable Documentation permits installation on non-Avaya equipment) for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

Each vAppliance will have its own ordering code. Note that each instance of a vAppliance must be separately ordered. If the end user customer or Avaya channel partner would like to install two of the same type of vAppliances, then two vAppliances of that type must be ordered.

Each Product has its own ordering code. Note that each instance of a Product must be separately licensed and ordered. "Instance" means one unique copy of the Software. For example, if the end user customer or Avaya channel partner would like to install two instances of the same type of Products, then two Products of that type must be ordered.

Third Party Components

"Third Party Components" mean certain software programs or portions thereof included in the Software that may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the Documentation or on Avaya's website at: <http://support.avaya.com/Copyright>. You agree to the Third Party Terms for any such Third Party Components.

Note to Service Provider

The Product may use Third Party Components that have Third Party Terms that do not allow hosting and may need to be independently licensed for such purpose.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners. Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: <http://support.avaya.com>.

Contact Avaya Support

See the Avaya Support website: <http://support.avaya.com> for product notices and articles, or to report a problem with your Avaya product. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <http://support.avaya.com>, scroll to the bottom of the page, and select Contact Avaya Support.

Contents

1. Telephone Overview

1.1 T7000 Telephone.....	9
1.2 Which Telephone System?.....	9
1.3 Button Functions.....	10
1.4 Feature Codes.....	11
1.5 Short Codes.....	12
1.6 Tones.....	14
1.7 What's My Extension Number?.....	15
1.8 Notes.....	15

2. Making Calls

2.1 Virtual Call Appearances.....	18
2.2 Setting a Callback.....	19
2.3 Redial the Previous Number.....	19
2.4 Making a Page Call.....	20
2.5 Direct Voice Calls.....	20
2.6 Making a Priority Call.....	20
2.7 Using Speed Dials.....	21

3. Answering Calls

3.1 Answering a Page Call.....	24
3.2 Call Pickup.....	25

4. Call Controls

4.1 Adjust the Call Volume.....	28
4.2 Switching Between Calls.....	28
4.3 Transferring Calls.....	29
4.4 Transferring a Held Call.....	29
4.5 Handsfree Speaker Operation.....	29
4.6 Headset Operation.....	29
4.7 Ending Calls.....	29
4.8 Groups.....	30

5. Holding and Parking Calls

5.1 Parking Calls.....	35
5.1.1 Traditional Park.....	35
5.1.2 Park & Page.....	35
5.2 Holding Calls.....	36
5.2.1 Transferring a Held Call.....	36

6. Conference Calls

6.1 Starting a Conference.....	38
6.2 Adding a Call to a Conference.....	38
6.3 Holding a Conference Call.....	39
6.4 Transferring Calls Using Conference.....	39

7. Voicemail

7.1 Message Waiting Indication.....	42
7.2 Checking Messages.....	42

8. Logging In/Out

8.1 Logging In on a Phone Already in Use.....	45
8.2 Logout.....	45

9. Redirecting Calls

9.1 Follow Me.....	49
9.2 Forwarding Calls.....	50

9.2.1 Forward Unconditional.....	51
9.2.2 Forward on Busy.....	52
9.2.3 Forward on No Answer.....	53
9.3 Do Not Disturb.....	54
9.4 Twinning.....	55

10. Phone Settings

10.1 Ringer Sound.....	58
10.2 Ringer Volume.....	58

11. Button Programming

11.1 Erasing a Button.....	60
11.2 Auto Dial Button.....	61
11.3 Internal Auto Dial (User Button).....	61
11.4 Feature Button.....	62
11.5 Button Functions.....	63
11.5.1 Automatic Intercom.....	63
11.5.2 Call Forwarding All.....	63
11.5.3 Conference.....	63
11.5.4 Do Not Disturb.....	63
11.5.5 Hunt Group Night Service.....	63
11.5.6 Internal Auto Answer.....	63
11.5.7 Last Number Redial.....	63
11.5.8 Page Group.....	64
11.5.9 Priority Call.....	64
11.5.10 Ring Again.....	64
11.5.11 Speed Dial.....	64
11.5.12 Speed Dial [nnnn].....	64
11.5.13 Transfer.....	64
11.5.14 User BLF.....	64
11.5.15 Voicemail.....	64

12. Glossary

12.1 Abbreviated Ring.....	66
12.2 Appearance Button.....	66
12.3 Attention Ring.....	66
12.4 Auto Hold.....	66
12.5 Bridged Appearance Button.....	66
12.6 Call Appearance Button.....	66
12.7 Call Coverage Button.....	66
12.8 Do Not Disturb.....	66
12.9 Do Not Disturb Exceptions.....	67
12.10 Follow Me.....	67
12.11 Follow Me Here.....	67
12.12 Follow Me To.....	67
12.13 Forward on Busy.....	67
12.14 Forward on No Answer.....	67
12.15 Forward Unconditional.....	67
12.16 Group.....	68
12.17 Idle Line Preference.....	68
12.18 Internal Twinning.....	68
12.19 Line Appearance Button.....	68
12.20 Logged Out.....	68
12.21 Login Code.....	68
12.22 Missed Call.....	68
12.23 Missed Group Call.....	68
12.24 Mobile Twinning.....	69
12.25 Park Call.....	69
12.26 Park Slot Number.....	69

12.27 Ringing Line Preference.....	69
12.28 Short Codes.....	69
12.29 Small Community Network.....	69
12.30 System Administrator.....	69
12.31 System Phone User.....	69
12.32 Twinning.....	69

13.Document History

Index	73
-------------	----

Chapter 1.

Telephone Overview

1. Telephone Overview

1.1 T7000 Telephone

On IP Office, the T7000 telephone is supported by IP500v2 IP Office systems running IP Office Release 7.0 and higher software. This guide is for IP Office Standard Version mode, separate user guides exist for other IP Office operation modes.



These phones use [virtual call appearances](#)^[18]. Virtual call appearances allow you to use the **HOLD** button on the phone to switch between each of your phone's call appearance buttons (normally 3), each of which represents a call that you can make or receive.

04	Last Number Redial ^[63]
05	Call Forwarding All ^[63]
06	Transfer ^[64]
07	Conference ^[63]

Feature	Hold	
1	2	3
4	5	6
7	8	9
*	0	#
-	Volume	+





1.2 Which Telephone System?

The IP Office telephone system can operate in a number of modes. This guide is for a system operating in IP Office Standard Version mode.

To check what system you are one, press **Feature 9*80**. If your system is a IP Office Standard Version system, you will hear an error tone.

1.3 Button Functions

In addition to the standard buttons 0 to 9, * and # buttons for dialing, the phone also has the following additional keys listed below. Some buttons may use either icons or words depending on your locale and the particular model of the phone that you have.

-  **Hold**
Cycle between calls and dial tone.
-  **Feature**
This key is used to access a range of special functions by pressing the key and then [dialing a feature code](#)^[11].
-  **Volume Controls** 
Increase or decrease the volume during a call.
-

The button layout is indicated below. The double-digits are the button numbers for [programmable buttons](#)^[60]. The default function for those buttons is indicated. The function for each programmable button can be set by you or by your system administrator.

04	Last Number Redial ^[63]
05	Call Forwarding All ^[63]
06	Transfer ^[64]
07	Conference ^[63]

Feature		Hold
1	2	3
4	5	6
7	8	9
*	0	#
-	Volume	+

1.4 Feature Codes

The phone can access a range of functions by pressing the phone's **Feature** key and dialing the required feature code.

- **Speed Dial:** *Feature 0 <index>*
Dial a stored number. Follow it with a 3-digit number system speed dial (000 to 999) or * and a 2-digit number personal speed dial (00 to 99).
- **Ring Again:** *Feature 2 (Set)/Feature #2 (Clear)*
Set a ringback on the extension being called. When the target extension ends its current call, you are rung and when you answer, a new call is made to the target.
- **Conference:** *Feature 3*
Turn the current call and any held call or calls into a conference call. The held call can be an existing conference to which you want to add another call.
- **Forward Unconditional On:** *Feature 4 <number> (On)/Feature #4 (Off)*
Switch on and off immediate forwarding of calls to the number entered.
- **Last Number Redial:** *Feature 5*
Redial the last number dialed. This code can only be used when the phone is currently idle.
- **Page:** *Feature 60 <number>*
Make a page call to an extension or group. The target extension or group members must be free and must support handsfree auto-answer in order to hear the page.
- **Retrieve Messages:** *Feature 65 or Feature 981*
Access your voicemail mailbox to collect messages.
- **Dial Voice Call:** *Feature 66 <number>*
Have a call automatically answered on speaker phone after 3 beeps. If the extension is not free when called, the call is presented as a normal call.
- **Transfer:** *Feature 70 <number>*
Put your current call on hold and make an transfer enquiry call to another number. Pressing **Feature 70** again to completes the transfer.
- **Call Park/Park & Page:** *Feature 74*
Park your current call. The additional functions and method for unparking calls depends on whether Park & Page is configured on your system or not. See [Parking Calls](#) ^[35].
- **Call Unpark:** *Feature #74 <park slot number>*
Unpark a call. The code is followed by the park slot number used to park the call.

1.5 Short Codes

In addition to the [Feature codes](#)^[11] supported by the phone, you can also dial short codes provided by the telephone system. These are useful as they can be dialed from any type of phone on the system.

Some short codes require you to enter additional information when you dial them, typically an extension number. That is indicated by **N** in the short codes shown below.

The short codes below are default short codes that may be supported by your telephone system. Your system administrator can add, remove or edit the short codes.

Park/Unpark

- **Park Call: *37*N#**
Parks the held call using the park slot number dialed in place of **N**.
- **Unpark Call: *38*N#**
Unpark the call parked in park slot number **N**.

Call Pickup

- **Pickup Any Call: *30**
Answer a call ringing on the telephone system.
- **Pickup a Group Call: *31**
Answer a call ringing a group of which you are a member. You can use this function even if your group membership is set to disabled.
- **Pickup a Users Call: *32*N#**
Pickup a call ringing a user's extension number (**N**).
- **Pickup a Group Members Call: *53*N#**
Pickup a call ringing the members of a group (**N**). This does not necessarily have to be a group call.

Conference

- **Conference Held Calls: *47**
Start a conference between yourself and any calls that you have on hold.

Do Not Disturb

- **Switch Do Not Disturb On: *08**
Set your phone to do not disturb.
- **Switch Do Not Disturb Off: *09**
Switch off do not disturb.
- **Add a Do Not Disturb Exception Number: *10*N#**
Add a number (**N**) to your list of do not disturb exceptions.
- **Delete a Do Not Disturb Exception Number: *11*N#**
Remove a number (**N**) from your list of do not disturb exceptions.
- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.

Follow Me

- **Follow Me Here: *12*N#**
Dialed at the extension to which you want you calls redirected. Use your own extension number (**N**) when dialing the short code.
- **Follow Me Here Cancel: *13*N#**
Dialed at the extension to which you want your calls were redirected. Use your own extension number (**N**) when dialing the short code.
- **Follow Me To: *14*N#**
Dialed at your phone. Dial the extension number (**N**) to which you want your calls redirected. You can dial just ***14#** to cancel follow me.
- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.

Forwarding

- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.
- **Set the Forward Unconditional Destination: *07*N#**
Set the destination number (**N**) for forward unconditional when it is switched on.
 - **Switch Forward Unconditional On: *01**
Switch on forward unconditional. A destination must have been set.
 - **Switch Forward Unconditional Off: *02**
 - **Include Group Calls in Forward Unconditional: *50**
 - **Exclude Group Calls from Forward Unconditional: *51**
- **Set the Forward On Busy/No Answer Destination: *57*N#**
Set the destination number (**N**) for forward on busy and forward on no answer. If no number has been set, those functions will use the forward unconditional number if set.
 - **Switch Forward On Busy On: *03**
 - **Switch Forward On Busy Off: *04**
 - **Switch Forward on No Answer On: *05**
 - **Switch Forward on No Answer Off: *06**

Group

- **Night Service Status On: *20*N#**
Set a group into night service status by entering its extension number (**N**).
- **Night Service Status Off: *21*N#**
Take a group out of night service status by entering its extension number (**N**).

Login

- **Login: *35*N*L#**
Login to a phone using your extension number (**N**) and login code (**L**).
- **Log Out: *36**
Log yourself out from the phone where you are currently logged in.

Voicemail

- **Check Messages: *17**
Access mailboxes to check for messages.
- **Voicemail On: *18**
Allow voicemail to be used to answer calls.
- **Voicemail Off: *19**
Stop voicemail being used to answer calls.
- **Voicemail Ringback On: *48**
Have voicemail ring your phone when you have any new messages. It will call when you use the phone.
- **Voicemail Ringback Off: *49**
Switch off ringback.

1.6 Tones

In addition to ringing, you may hear the following tones:

- **Page Call:** *Single Loud Beep*
This tone indicates that your phone is receiving a [page call](#)^[20]. You do not need to take any action to hear the call and you cannot be heard by the person doing the page.
- **Short Code Confirmation:** *2 Loud Beeps*
These tones are heard when using [short codes](#)^[12]. It is a confirmation that the short code function has been completed.
- **Direct Voice Call:** *3 Loud Beeps*
These tones are heard when receive a direct call which has been automatically answered by the phone. You can hear the caller and then can hear you.
- **Waiting:** *4 Loud Beeps*
These tones are heard if the phone has been waiting for you to complete dialing or the number you have dialed is invalid. The tones are repeated until you hang up.
- **Incompatible:** *Warble tone*
This continuous high-low tone is heard if the number dialed is not valid for routing by the telephone system or any system function. .

You may hear the following tones during calls:

- **Conference Tones:** *Single Tone/Double Tone*
During a call, a single tone indicates that someone else has joined the call. A double tone indicates that someone has left the conference. The system administrator can replace these with a repeating single tone every 10 seconds.
- **Held Tone:** *Double tone every 4 seconds.*
If the system does not have music on hold configured, this repeated double tone is used to inform you that your call has been put on hold by the other system user.

T7000 Special Tones

As the T7000 does not have a display, it uses a number of additional tones that are heard when using the **Feature** button.

- **Confirmation Tone:** *A high pitch single beep.*
This tone indicates that the requestion action has been performed. (e.g., Feature button pressed invoking feature session).
- **Waiting for Input Tone:** *A low pitch single beep.*
This tone indicates that the phone is waiting for you to enter some data or press a button.
- **Error Tone:** *A high-low double beep.*
This tone indicates that the process has failed, timed-out or is not supported by the T7000 phone.

1.7 What's My Extension Number?

The label under the handset is normally used to record the extension number of the phone. This is normally a fixed number. However, the telephone system supports users [logging in](#) to an extension when they want to use it, changing its extension number to match their own when they do so.

Unfortunately for this type of phone there is no simple way to find out the phone's current extension number. Make a call to a colleague who has a phone with a display. They will see the extension number your phone.

1.8 Notes

This guide was written assuming that the telephone system and your phone are using their default settings. However, the system has a wide range of controls and features that can be used to customize its operation and that of your phone. Your system administrator will inform you if they change any settings that will affect you or the operation of your phone.

Other Phones

The T7000 is one of a range of similar phones that are supported by the telephone system. Most of the Feature codes supported by the T7000 can also be used on these other phones.

		M7100/ M7100N	M7208/ M7208N	M7310/ M7310N	M7324/ M7324N	T7000	T7100	T7208	T7316	T7316
Display		✓	✓	✓	✓	-	✓	✓	✓	✓
Display Soft Keys		-	-	✓	✓	-	-	-	✓	✓
Virtual Call Appearances		✓	-	-	-	✓	✓	-	-	-
Handsfree Operation	Speaker	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Microphone	-	✓	✓	✓	-	-	✓	✓	✓
Headset Operation	Socket	-	✓	✓	✓	-	-	✓	✓	✓
	Button	-	-	-	-	-	-	✓	✓	✓
Programmable Buttons...		1	7	33	23	4	1	7	15	16
... with icons		-	7	9	23	-	-	7	15	16
... without icons		1	-	24	-	4	1	-	-	-

Chapter 2.

Making Calls

2. Making Calls

If the phone is idle, dial the number required. You will be able to hear the call progress. When you need to speak pickup the handset.

If you already have a call in progress, you can use  **Hold** key to cycle between your current call, any other held or waiting calls and dial tone.

2.1 Virtual Call Appearances





Each call appearance button assigned to your phone by the system administrator represents a call that you can make or answer. Rather than having physical buttons assigned as call appearance buttons, this phone uses virtual call appearances. While you can only be connected to one call at any time, you can easily switch between it and of your other virtual call appearances.

Typically the maximum number of simultaneous calls allowed is 3. This is set by your system administrator. When all your virtual call appearances are in use, you are busy to any further calls. Those calls will follow your forward on busy if set, else go to voicemail is available or else just get busy indication.

Virtual Call Appearance Usage


When you go off-hook by lifting the handset, you answer the alerting call if any, otherwise you hear dial tone and can make a call. This uses one of your virtual call appearances.

With a call connected:

- If another call arrives on another virtual call appearance, you will hear a call waiting tone.
- If you press  **Hold**, the connected call is placed on hold and one of the following occurs, in the order listed.
 1. If you have a call waiting, that call is answered.
 2. If you have any free virtual call appearances available, you will hear dial tone. This allows you to make a call or to use short codes that control your held or waiting calls. The following are some of the default [short codes](#)  that you can use:
 - ***26: Clear CW**
Release the previous call and answer the waiting call.
 - ***52: Clear Call**
Release the previous call.
 - ***47: Conference Add**
Start a conference between yourself and any held calls.
 3. If you have a call on hold, that call is reconnected.
- You can press  **Hold** again to cycle through the options above.
- If you replace the handset (go on-hook) during a call, the current call is ended and your phone returns to idle. If there is a waiting call, it starts ringing. You can answer the call by lifting the handset again or pressing .

With the phone idle:

When you lift the handset, the following may occur in the order listed:

- The first alerting call appearance is answered if any.
- The first free call appearance available is seized and you hear dial tone to make a call.
- You can press  **Hold** to switch between virtual call appearances. This will answer or retrieve any call on next virtual call appearance or else play dial tone to make a call.

With the phone idle but a call alerting:

- Going off-hook or pressing  **Hold** will answer the call.

2.2 Setting a Callback

If you call another internal user and they do not answer, you can set a callback. When you have a callback set, the system will call you when the other user next uses ends a call. When you answer the callback, the system will automatically make another call to the user.

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.

To Set a Callback

1. While the call is still ringing or if you hear busy, press **Feature 2**
2. End your call attempt.

To Clear a Callback

If you have a callback set, you can cancel it using the following process:

1. Press **Feature #2**.

2.3 Redial the Previous Number

You can redial the number of the last outgoing call that you made.

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.
1. To redial the last number called, press **Feature 5**.

2.4 Making a Page Call

You can make a page call to another user or to the available members of a group. The users do not have to take any action to hear the page.

The phones called must support handsfree auto-answer in order to hear the page. If they do not, they do not receive any alerting call.

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.
 1. Press **Feature 60**.
 2. Dial the number of the user or group you want to page.
 - If the destination is a user and they already have a call connected, they cannot be paged. If the destination is a group which is not in service or has no available members, it cannot be paged.

2.5 Direct Voice Calls

This feature is also called dial voice call or direct voice call. It calls another extension and has the call automatically answered on handsfree speaker after playing 3 beeps. If the called extension does not have a handsfree microphone, the user must use the handset if they want to talk.

The called extension called must support a handsfree speaker. If the extension does not or if the extension is not free when called, the call is alerts as a normal call.

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.
 1. Press **Feature 66**.
 2. Dial the target user extension number.

2.6 Making a Priority Call

A priority call allows you to call another user even if they have 'do not disturb' set. The call will follow any forwarding and follow me settings they have in use but will not go to voicemail.

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.
 1. Press **Feature 69**.
 2. Dial the target user extension number.

2.7 Using Speed Dials

Speed dials are telephone numbers that are stored by the telephone system. There are two types of speed dial: personal speed dials and system speed dials.

You or your system administrator can enter numbers that you want stored as personal speed dials. These are only useable by you. Your system administrator can also store numbers as system speed dials. Those are useable by all users on the system including you.

If you have any internal or external number that you dial frequently, you can store those as an [auto dial button](#)⁶¹ rather than a speed dial.

Dialing a Speed Dial

This function can be assigned to a programmable button. This allows it to be accessed in a single key press.

1. Press **Feature 0**.

- **To dial a personal speed dial:**

Dial * followed by the 2-digit personal speed dial number between **00** to **99**. Alternatively you can dial the 2-digit personal speed dial number and then press **#**.

- **To dial a system speed dial:**


Dial the 3-digit system speed dial number between **000** to **999**.



Chapter 3.

Answering Calls

3. Answering Calls

The phone's message lamp will flash when you have a call waiting to be answered. Lift the handset to answer the call or press  **Hold**.

You can then use the  **Hold** key to cycle between your current call, any held calls and dial tone.

3.1 Answering a Page Call

You can be paged if you have no call in progress or only held and or parked calls. After a single tone, the page is heard through the phone's speaker. If you are currently on a call or set to do not disturb your phone is not paged.

You cannot answer a page call.

3.2 Call Pickup

Pickup is used to answer a call ringing elsewhere on the phone system. There are a number of pickup options:

- Answer any ringing call on the telephone system.
- Answer a call ringing a particular user.
- Answer a call ringing a particular group.
- Answer a call, not necessarily a group call, ringing the members of a group.

Default Short Codes

[Short codes](#)^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Pickup Any Call: *30**
Answer a call ringing on the telephone system.
- **Pickup a Group Call: *31**
Answer a call ringing a group of which you are a member. You can use this function even if your group membership is set to disabled.
- **Pickup a Users Call: *32*N#**
Pickup a call ringing a user's extension number (*N*).
- **Pickup a Group Members Call: *53*N#**
Pickup a call ringing the members of a group (*N*). This does not necessarily have to be a group call.

Chapter 4.

Call Controls

4. Call Controls

4.1 Adjust the Call Volume

While talking, you can adjust the volume of the incoming call. The volume is separately adjusted for whichever device you are currently using (handset or speaker).

1. With the call connected, press the  and  keys to adjust the volume.

4.2 Switching Between Calls

You can use the  **Hold** key to cycle between your virtual call appearances including held calls and dial tone.


4.3 Transferring Calls

To transfer a call, your phone must have an available call appearance button. If all your current call appearance buttons are in use, you must either [end](#)²⁹ or [park](#)³⁵ one of your existing calls.

- Your system administrator can configure the system so that it will attempt to return unanswered transfers to you.

1. Dial **Feature 70**. The current call is automatically put on hold.

2. Dial the number for the transfer destination.

- To complete the transfer, press **Feature 70** again. You can do this while the call is still ringing or you can wait until it is answered.
 - Transferring a call while it is still ringing is called an unsupervised or blind transfer.
 - Transferring a call after ringing finishes is called a supervised or announced transfer.
- If the transfer destination does not answer or, after answering the call, does not want to accept the call:
 - To try another number, replace the handset.
 - To cancel the transfer attempt, press  **Hold**.

4.4 Transferring a Held Call

When you already have a call on hold and a call connected, you can connect them by starting a conference. Press **Feature 3**. Your current call and the held call will be connected. You can now drop yourself from the conference.

4.5 Handsfree Speaker Operation

The phone has a handsfree speaker but does not have a handsfree microphone. This means that you can make and answer calls handsfree but in order to speak you must lift the handset.

- You can make a handsfree call by simply dialing without lifting the handset. You can hear the call progress and when answered, lift the handset to continue the call.
- The speaker allows the phone to receive [page calls](#)²⁰. You can hear the page without needing to take any action. However, you cannot answer the page.
- The speaker allows the phone to auto answer [direct voice](#)²⁰ calls. You can hear the caller but they will not be able to hear you until you lift the handset. The same applies for calls from other users if you have [internal auto-answer](#)⁶³ set on the phone.

4.6 Headset Operation

The phone does not have a socket for connecting a headset.

4.7 Ending Calls

If the call is connected on the phone's handset, replacing the handset will end the call.

4.8 Groups

Your system administrator can include you as a member of a group or groups along with other users. Each group has its own extension number which is used to call the group.

When a call is presented to a group, it is presented to the available group members, either one at a time or all at the same time, until answered by one of the members.

How long a group call will ring at each group member's phone before being presented to the next member is controlled by the group's own settings. Groups also use voicemail and have their own settings for when an unanswered call should go to the group's mailbox. For group calls, the group's own voicemail settings are used rather than your settings.

Default Short Codes

[Short codes](#)^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Night Service Status On: *20*N#**
Set a group into night service status by entering its extension number (**N**).
- **Night Service Status Off: *21*N#**
Take a group out of night service status by entering its extension number (**N**).

Chapter 5.

Holding and Parking Calls

5. Holding and Parking Calls

Holding a call and parking a call are two similar actions. The table below summarizes the main differences between parking a call or holding a call.

When a call is ...	Held	Parked
... the call occupies an appearance button.	Yes	No
... the caller hears music on hold or hold reminder tones.	Yes	Yes
... the call can be retrieved by other users.	No	Yes
... the call recalls to you automatically after a time.	Yes Default 15 seconds	Yes Default 5 minutes.
... the call can be used to start or add calls to a conference.	Yes	No
... the call is assigned a unique ID.	No	Yes

5.1 Parking Calls

Parking a call is similar to holding a call. However, parked calls can be unparked by other users on the phone system.

Calls that you park recall to your phone (when idle) if they have been parked for too long. The default timeout is 5 minutes but can be changed by the system administrator. Recall calls ignore any forwarding or do not disturb settings that you have set.

For IP Office Release 9.0 and higher, call park can operate in two different ways:

- [Traditional Park](#) ^[35]
- [Park & Page](#) ^[35]

Default Short Codes

[Short codes](#) ^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Park Call: *37*N#**
Parks the held call using the park slot number dialed in place of **N**.
- **Unpark Call: *38*N#**
Unpark the call parked in park slot number **N**.

5.1.1 Traditional Park

This method of parking calls is used if [Park & Page](#) ^[35] is not configured on the telephone system. Your system administration will confirm which way your system operates.

If you park a call without specifying a park slot number, the system automatically assigns a park number based on your extension number plus a single digit. For example, for extension 201, the first parked call uses park slot number 2010 if available. For the T7000, only the single automatic park slot of extension number plus 0 is used.

Call park buttons can be configured to match specific park slot numbers. A call parked using that button is given that park slot number. All users with a call park button set to the same number can see when there is a parked call there and can unpark that call using their button.

To Park a Call

1. Press **Feature 74**. The call is parked with the park slot number consisting of your extension number and 0 if that park slot is empty. If that park slot is not empty, you will hear a high-low double beep error tone and will still be connected to the caller.

5.1.2 Park & Page

This method of parking calls is used if Park & Page is configured on the telephone system. Your system administration will confirm which way your system operates.

Park and page uses a set of pre-configured park slot numbers that act like extension numbers. When you parked a call in one of those park slots, you or any other user on the system can dial that park slot number to unpark the call.

As the T7000 has no display, it can only park a single call and only into the first park slot number configured by your system administrator. If that park slot already contains a call, the additional call is not parked.

To Park a Call


1. Press **Feature 74**. The call is parked in the first park slot if it is available. If that park slot is not empty, you will hear a high-low double beep error tone and will still be connected to the caller.

To Unpark a Call

1. Dial the park slot number that was assigned to the parked call.

5.2 Holding Calls

You can hold as many calls as your phone can receive.

- The held call will still occupy the call appearance on which it was made or answered.
- While held, the caller will hear music on hold. If your system does not have music on hold available, the caller will hear double beep tones every few seconds.
- If you have more than one call on your phone, either held or connected, you can [start a conference](#)  between yourself and the calls.

Calls that you have held will recall to your phone when it is idle if they have been on hold for too long. The default hold timeout for the telephone system is 15 seconds but it can be changed by the system administrator. Hold recall calls ignore any forwarding or do not disturb settings you have set.

Important - Holding Conference Calls

You can hold a conference call in the same way as holding a normal call. Holding the conference call does not affect the other conference parties who can continue talking. You will also still be listed as a member of the conference call in the conference details.

- **! Warning**

This only applies to conference calls hosted by your own telephone system. Holding your call to a conference hosted on another telephone system will cause that conference to hear your system's music on hold.

You can use the  **Hold** key to cycle between your virtual call appearances including held calls and dial tone.

5.2.1 Transferring a Held Call

When you already have a call on hold and a call connected, you can connect them by starting a conference. Press **Feature 3**. Your current call and the held call will be connected. You can now drop yourself from the conference.

Chapter 6.

Conference Calls

6. Conference Calls

Multiple conference calls are supported, with parties addable to each conference call until the system's total conference capacity (128) is reached. However, a maximum of 64 parties is supported in any particular conference call.

Conference resources are also used for call recording and other features, reducing the available conference capacity for ordinary conference calls.

Note that some conference controls, for example dropping other parties, only apply for conferences started on the same phone system as your extension.



Default Short Codes

[Short codes](#) ⁽¹²⁾ are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Conference Held Calls: *47**
Start a conference between yourself and any calls that you have on hold.



6.1 Starting a Conference

If you have a connected call and any held calls, pressing **Feature 3** will start a conference between you and those calls. If you do not already have a held call, you can use the process below to start a conference.

1. Make a call to the first party or answer a call.
2. Place the call on hold by pressing  **Hold** or **Feature 3**.
3. Dial the party that you want to add to the conference.
4. If they answer and want to join the call, press **Feature 3**.
5. If they do not want to join the call or do not answer, replace the handset. Return to the held call by pressing  **Hold**.

6.2 Adding a Call to a Conference

You can add additional parties to an existing conference.


1. Press  **HOLD** or **Feature 3** to put the conference on hold.
2. This does not affect the other conference parties who can continue talking to each other.
3. Dial the party that you want to add to the conference.
4. If they answer and want to join the call, press **Feature 3**.
5. If they do not want to join the call or do not answer, replace the handset. Return to the held call by pressing  **Hold**.


Important - Holding Conference Calls

You can hold a conference call in the same way as holding a normal call. Holding the conference call does not affect the other conference parties who can continue talking. You will also still be listed as a member of the conference call in the conference details.

- **! Warning**
This only applies to conference calls hosted by your own telephone system. Holding your call to a conference hosted on another telephone system will cause that conference to hear your system's music on hold.

6.3 Holding a Conference Call

Using the  **Hold** key you can put a conference call on hold in the same way as you can for a normal call.

To take the conference off hold, press  **Hold**.

Important - Holding Conference Calls

You can hold a conference call in the same way as holding a normal call. Holding the conference call does not affect the other conference parties who can continue talking. You will also still be listed as a member of the conference call in the conference details.

- **! Warning**

This only applies to conference calls hosted by your own telephone system. Holding your call to a conference hosted on another telephone system will cause that conference to hear your system's music on hold.

6.4 Transferring Calls Using Conference

When you already have a call on hold and a call connected, you can connect them by starting a conference. Press **Feature 3**. Your current call and the held call will be connected. You can now drop yourself from the conference.

Chapter 7.

Voicemail

7. Voicemail

If enabled, voicemail is used to answer calls to you that have rung unanswered for your "no answer time", the default is 15 seconds. It is also used to answer calls when you have do not disturb enabled. The message lamp on your phone is lit when you have new messages in your mailbox.

Default Short Codes

[Short codes](#) ^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Check Messages: *17**
Access mailboxes to check for messages.
- **Voicemail On: *18**
Allow voicemail to be used to answer calls.
- **Voicemail Off: *19**
Stop voicemail being used to answer calls.
- **Voicemail Ringback On: *48**
Have voicemail ring your phone when you have any new messages. It will call when you use the phone.
- **Voicemail Ringback Off: *49**
Switch off ringback.

7.1 Message Waiting Indication

Most phones have a message waiting lamp. The message lamp is lit when you have new messages in your voicemail mailbox. It remains lit until you have played each of the new messages. The system administrator can also configure it so that you receive new message waiting indication for a group or groups.

The icon of a programmable button [programmed](#) ^[62] to **Feature 65** will act as a message waiting indicator for new messages. That button can then also be used to access the mailbox.

7.2 Checking Messages

1. Press **Feature 65** or **Feature 981**.
 - Depending on how your voicemail system is configured, you may be asked to entered your voicemail code.
2. Follow the voice prompts provided by the system. For help press either 8 or *4.

Notes

1. Automatic Message Deletion

By default, messages are automatically deleted a set time after being played. The delay depends on the particular voicemail server (24 hours for embedded voicemail, 30 days for Voicemail Pro). For voicemail messages on a Voicemail Pro system, the system administrator can customize the delay and can also apply automatic deletion times to new and saved messages.

Chapter 8.

Logging In/Out

8. Logging In/Out

You may always use the same phone in the same location. However, the telephone system provides features that allow you to use any phone on the system to make and receive your calls. To do this your system administrator need to assign you a login code.

- **Log In** ^[45]
You can login on any phone that you want to use. When you login to a phone, you take control of that phone. Incoming calls for you are redirected to that phone and your user information and settings are available^[1]. Any existing user on the phone is logged off when you login.
 - Any existing user of the phone is logged out while you are logged in.
 - If you were logged in on another phone, you are logged out from that phone.
 - If your phone system is in a [Small Community Network](#) ^[69] of phone systems, it may be possible to login at extensions located on other phone systems in the network. Your system administrator will advise you if you can remote hot desk and what features will still be available to you when you do.
- **Log Out** ^[45]
When you log out from a phone (or are logged out by another user logging in), the telephone system may apply several actions:
 - If you have a normal default extension and no one else is logged in there, you return to being logged in on that phone.
 - If you remain logged out, you are treated the same as being on do not disturb except that all calls to you go to voicemail if available.
 - If you have a mobile twinned number, the system administrator can configure the system so that calls are still presented to your mobile twin while you are logged out.
- **Default Extension**
Each extension can be configured with a default user. If you are logged off from an extension, if you have a default extension the system will automatically log you in at your default extension if it is not in use by another user.
- **Login Idle Period**
Your system administrator can configure a timeout which will automatically log you out if you do not use the phone in that time to make or answer a call.

Default Short Codes

[Short codes](#) ^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Login: *35*N*L#**
Login to a phone using your extension number (**N**) and login code (**L**).
- **Log Out: *36**
Log yourself out from the phone where you are currently logged in.

Note

1. User information stored by the telephone system, for example call log, contacts directory and speed dials, moves with you when you login on different phones. However this only applies when moving between 1400, 1600, 9400, 9500, 9600, M-Series, T-Series phones. Other phone types store the information on the phone and that information does not move with you when you login or out.

8.1 Logging In on a Phone Already in Use

If you have a login code, you can login at a phone that is already in use by another user. The existing user is logged out.

1. Dial the short code for logging in. The default is ***35*N*L#** where **N** is replaced by your extension number and **L** by your login code.

8.2 Logout

You can only log yourself out if you have been given a login code by your system administrator. Otherwise, the only way to be logged out is if someone else logs in on your phone. When that happens, if you are not automatically logged back in when they log off or if you want to login over them, you can login again using the login process with a blank password .

If you have a login code, to logout dial ***36**.

Chapter 9.

Redirecting Calls

9. Redirecting Calls

This section looks at the different ways that you can redirect your calls to another phone.

- **Follow Me** ⁴⁹

Temporarily redirect all your calls to another phone that you will be sharing with that phone's normal user. This function can be used in two ways:

 - **Follow Me To**
Set the follow me destination from your own phone.
 - **Follow Me Here**
Set the follow me from the phone that you want to share.
- **Forward** ⁵⁰

Forward calls to an internal or external number.

 - **Forward on Busy**
Forward calls when you have reached the limit of the number of calls that the phone can present to you.
 - **Forward on No Answer**
Forward calls if they have rung unanswered at your phone.
 - **Forward Unconditional**
Immediately forward calls. Forwarding to voicemail can be selected as an option.
- **Do Not Disturb** ⁶³

Redirect all calls to voicemail if available or otherwise to busy tone.

 - You can set do not disturb exception numbers for calls to which do not disturb if not applied.
 - Other users can make [priority calls](#) ²⁰ to override your do not disturb.
- **Twinning** ⁵⁵

Twinning is a process whereby you can have your calls ring at two different phones. You can answer calls at either phone. There are two variants of twinning, internal twinning which uses two internal extensions and mobile twinning which twins your internal extension with an external number.

Method		Calls Redirected			Destination		
		Internal	External	Group	Internal	External	Voicemail
Follow Me	Follow Me To	✓	✓	✓	✓	✗	✗
	Follow Me Here	✓	✓	✓	✓	✗	✗
Forward	Forward on Busy	✓	✓	✗	✓	✓	✗
	Forward on No Answer	✓	✓	✗	✓	✓	✗
	Forward Unconditional	✓	✓	✓	✓	✓	✓
Do Not Disturb		✓	✓	✗	✗	✗	✓
Twinning		✓	✓	✓	✓	✓	✓

9.1 Follow Me

Follow me to is used to redirect your calls to another extension where you will be working. The calls are presented with your user name so that they can be distinguished from calls for the extensions normal user. This allows you to share another person's phone without logging them off their phone.

The calls are still subject to all your user settings as if they were ringing at your phone. All calls are redirected.

Follow Me To

Follow me to is the function used to enable follow me from your own phone.

Follow Me Here

Follow here is used to enable follow me at the extension to which you want your calls redirected.

Default Short Codes

[Short codes](#) ⁽¹²⁾ are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Follow Me Here: *12*N#**
Dialed at the extension to which you want you calls redirected. Use your own extension number (**N**) when dialing the short code.
- **Follow Me Here Cancel: *13*N#**
Dialed at the extension to which you want your calls were redirected. Use your own extension number (**N**) when dialing the short code.
- **Follow Me To: *14*N#**
Dialed at your phone. Dial the extension number (**N**) to which you want your calls redirected. You can dial just ***14#** to cancel follow me.
- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.

9.2 Forwarding Calls

Forwarding is used to redirect calls to another extension or an external number. The system supports 3 different types of forward.

- **Forward Unconditional** ^[51]
This forward is used immediately when it is switched on.
- **Forward on No Answer** ^[53]
This forward is used when a call alerts at your extension for too long without being answered. The normal default is 15 seconds.
- **Forward on Busy** ^[52]
This forward is used when you have no call appearances buttons available to on which to receive calls.

Default Short Codes

[Short codes](#) ^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.
- **Set the Forward Unconditional Destination: *07*N#**
Set the destination number (**N**) for forward unconditional when it is switched on.
 - **Switch Forward Unconditional On: *01**
Switch on forward unconditional. A destination must have been set.
 - **Switch Forward Unconditional Off: *02**
 - **Include Group Calls in Forward Unconditional: *50**
 - **Exclude Group Calls from Forward Unconditional: *51**
- **Set the Forward On Busy/No Answer Destination: *57*N#**
Set the destination number (**N**) for forward on busy and forward on no answer. If no number has been set, those functions will use the forward unconditional number if set.
 - **Switch Forward On Busy On: *03**
 - **Switch Forward On Busy Off: *04**
 - **Switch Forward on No Answer On: *05**
 - **Switch Forward on No Answer Off: *06**

9.2.1 Forward Unconditional

Forward unconditional is used to immediately redirect your calls.

- By default this function is only applied to incoming external calls to you. However, if required internal calls and or group calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward unconditional destination. That number can be internal or external.
- You can still use the phone to make outgoing calls. When you go off-hook you will hear broken dial tone.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

Default Short Codes

[Short codes](#)^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.
- **Set the Forward Unconditional Destination: *07*N#**
Set the destination number (*N*) for forward unconditional when it is switched on.
 - **Switch Forward Unconditional On: *01**
Switch on forward unconditional. A destination must have been set.
 - **Switch Forward Unconditional Off: *02**
 - **Include Group Calls in Forward Unconditional: *50**
 - **Exclude Group Calls from Forward Unconditional: *51**

9.2.2 Forward on Busy

Forward on busy redirects your calls when your phone is not able to present you with any more alerting calls.

- By default this function is only applied to incoming external calls to you. However, if required internal calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward on busy/no answer destination. That number can be internal or external.
- Busy is defined as having no available call appearance buttons on which further calls can be presented.
- Group calls are not presented when you are busy and so are not forwarded by this setting.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

Using a Programmable Button

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.

Default Short Codes

[Short codes](#) ⁽¹²⁾ are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.
- **Set the Forward On Busy/No Answer Destination: *57*N#**
Set the destination number (**N**) for forward on busy and forward on no answer. If no number has been set, those functions will use the forward unconditional number if set.
 - **Switch Forward On Busy On: *03**
 - **Switch Forward On Busy Off: *04**
 - **Switch Forward on No Answer On: *05**
 - **Switch Forward on No Answer Off: *06**

9.2.3 Forward on No Answer

Forward on no answer redirects calls that have alerted your phone but have not been answered for some reason.

- By default this function is only applied to incoming external calls to you. However if required internal calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward on busy/no answer destination. That number can be internal or external.
- No answer is defined as having been presented to your phone for your no answer time (default 15 seconds).
- Group calls are not forwarded.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

Using a Programmable Button

- This function can be assigned to a programmable button. This allows it to be accessed in a single key press.

Default Short Codes

[Short codes](#) ⁽¹²⁾ are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.
- **Set the Forward On Busy/No Answer Destination: *57*N#**
Set the destination number (**N**) for forward on busy and forward on no answer. If no number has been set, those functions will use the forward unconditional number if set.
 - **Switch Forward On Busy On: *03**
 - **Switch Forward On Busy Off: *04**
 - **Switch Forward on No Answer On: *05**
 - **Switch Forward on No Answer Off: *06**

9.3 Do Not Disturb

- When you are in 'do not disturb', your callers are redirected to voicemail if available or otherwise hear busy tone.
- People who call from numbers in your do not disturb exceptions list can still call you. Forwarding is set is applied to those calls.
- People who use a priority call function can also call you.
- Calls to any group of which you are a member are not presented to you (unless you are the last available member of the group).
- Enabling do not disturb will not affect any calls already being presented to your phone.
- You can still use the phone to make outgoing calls. When you go off-hook you will hear broken dial tone.

To Turn On Do Not Disturb

1. Press **Feature 85**.

To Turn Off Do Not Disturb

1. Press **Feature #85**.

Default Short Codes

[Short codes](#)^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

- **Switch Do Not Disturb On: *08**
Set your phone to do not disturb.
- **Switch Do Not Disturb Off: *09**
Switch off do not disturb.
- **Add a Do Not Disturb Exception Number: *10*N#**
Add a number (**N**) to your list of do not disturb exceptions.
- **Delete a Do Not Disturb Exception Number: *11*N#**
Remove a number (**N**) from your list of do not disturb exceptions.
- **Cancel All Forwarding: *00**
Switch off any forwarding. Includes forward unconditional, forward on busy, forward on no answer, follow me and do not disturb.

9.4 Twinning

Twining allow calls to you to ring at both your phone and at another number. The telephone system supports two types of twinning; internal twinning and mobile twinning.

Internal Twinning

This method of twinning twins your phone (your primary phone) with another internal extension (your secondary phone). Both phones are yours and share the same extension number. Your incoming calls will ring on both phones. You can make your calls from either extension.

A typical example for internal twinning would be a user who uses both a normal desk phone and also needs a mobile phone while moving around the building.

Your settings are applied to both phones. If the secondary is a 1400, 1600, 9400, 9500, 9600, M-Series, T-Series phone, it will share the same call log and personal directory contacts as available on your primary. Similarly, message waiting indication for your mailbox is show on both phones.

Mobile Twinning

Mobile twinning is twinning where your calls ring at both your phone and at another number which can be an external number.

You can assign a programmable button to turn twinning on or off and to set the number to which you are twinned.



Chapter 10.

Phone Settings

10. Phone Settings



10.1 Ringer Sound

You can change the ringer sound. This does not change the ring pattern which is controlled by the telephone system.

1. Press **Feature *6**.
2. Press **1** to **4** to select the required ringer sound.
 - Whilst the function is active, you can also use the  and  buttons to change the ringer volume.
3. The function will automatically cancel after a 5 seconds.

10.2 Ringer Volume

You can change the ringer volume using the following process. You can also adjust the volume while a call is ringing your phone.

1. Press **Feature *80**. The phone will start a continuous ring.
2. Use the  soft and loud  volume buttons to change the volume to the level required.
3. The function will automatically cancel after a 5 seconds.

Chapter 11.

Button Programming

11. Button Programming

The programmable button on your phone can be assigned a range of functions.


There are a number of methods that you can use for button programming:

- **Auto Dial Button** ^[61]: *Feature *1*
Store a number to be dialed by the button when it is pressed.
- **User Button (Internal Auto Dial)** ^[61]: *Feature *2*
Store another user's extension number to be dialed when the button is pressed.
- **Feature Button** ^[62]: *Feature *3*
Set a button to invoke a Feature code.
- **Function Button**: *Feature *3**
Set a button to invoke a selected telephone system function.
- **Default Buttons**: *Feature *3***
You can return the function of certain buttons back to their default for this type of phone.
- **Erase a Button** ^[60]: *Feature *1 Hold*
You can use the auto dial programming process but with a number to erase the current programming of a button.

Your system administrator can see and edit your button settings. They can also apply functions that you cannot program. Note that button user templates can be applied which will lock the function of certain buttons even if you try to change them.

11.1 Erasing a Button

The process for setting an [auto dial button](#) ^[61] can also be used to erase any programming on a programmable button.

1. Press **Feature *1**.
 - If you do not hear a high pitch confirmation tone, then the phone is waiting for you to enter your login code. Enter your login code and press #.
2. Press the button you want to erase. You cannot override any button configured to a [appearance function](#) ^[66] by your system administrator.
3. Press  **Hold**.

11.2 Auto Dial Button

A button set to this function dials a stored number. That number can be any number composed of the digits 0 to 9 plus * and #. It can be an internal or an external number. It can be a partial number that you complete dialing after pressing the button. It can also be a [system short code](#)^[12] for a telephone system feature. This button function is also known as Auto Dial and External Auto Dial.

- **! Warning**

This process will overwrite the existing function of a programmable button without any warning.

1. Press **Feature *1**.

- If you do not hear a high pitch confirmation tone, then the phone is waiting for you to enter your login code. Enter your login code and press #.

2. Press the button to program.

- You cannot override the programming of any button configured to a call appearance function by your system administrator.
- On buttons that you can program, any existing function is overwritten without warning.

3. Enter the number you want stored by the button. This can be a partial number which you will complete after pressing the button.

- The  button deletes the last digit entered.

4. When the number is complete, press  **Hold**.

11.3 Internal Auto Dial (User Button)

A button set to this function calls another user.

- **! Warning**

This process will overwrite the existing function of a programmable button without any warning.

1. Press **Feature *2**.

- If you do not hear a high pitch confirmation tone, then the phone is waiting for you to enter your login code. Enter your login code and press #.

2. Press the button to program.

- You cannot override the programming of any button configured to a call appearance function by your system administrator.
- On buttons that you can program, any existing function is overwritten without warning.

3. Enter the extension number of the user for who you want a button.

- The  button deletes the last digit entered.

4. As soon as a valid number is entered, the value is saved and the button set.

11.4 Feature Button

This process allows you to store some of the [Feature codes](#) that you can dial. You can then activate the feature using a single button press.

- **! Warning**

This process will overwrite the existing function of a programmable button without any warning.

1. Press **Feature *3**.

- If you do not hear a high pitch confirmation tone, then the phone is waiting for you to enter your login code. Enter your login code and press #.

2. Press the button to program.



- You cannot override the programming of any button configured to a call appearance function by your system administrator.
- On buttons that you can program, any existing function is overwritten without warning.

3. Enter the feature code of the function required.

- [Speed Dial](#) ^{[64]:} 0
- [Ring Again](#) ^{[64]:} 2
- [Conference](#) ^{[63]:} 3
- [Forward Unconditional On](#) ^{[63]:} 4
- [Last Number Redial](#) ^{[63]:} 5
- [Page](#) ^{[64]:} 60
- [Retrieve Messages](#) ^{[64]:} 65
- [Dial Voice Call](#) ^{[63]:} 66
- [Priority Call](#) ^{[64]:} 69
- [Time of Day](#): 803
- [Timer](#): 77
- [Transfer](#) ^{[64]:} 70
- [Directed Call Pickup](#): 76
- [Do Not Disturb](#) ^{[63]:} 85
- [Retrieve Messages](#) ^{[64]:} 981

11.5 Button Functions

The following is a quick summary of the various telephone system functions that you can set on a programmable button. This is not a comprehensive list of all button functions available, it only covers those that can be set by telephone users. The system administrator can assign other button functions and will inform you what those functions are if they do that.

Some button function use the directory to allow number selection. When this is the case, the  and  volume buttons are used to scroll through the list of matching names. If this is done during a call or while a call is alerting, this will also adjust the call or ring volume.

11.5.1 Automatic Intercom

A button set to this function makes an auto answered call to another extension.

This feature is also called dial voice call or direct voice call. It calls another extension and has the call automatically answered on handsfree speaker after playing 3 beeps. If the called extension does not have a handsfree microphone, the user must use the handset if they want to talk.

The called extension called must support a handsfree speaker. If the extension does not or if the extension is not free when called, the call is alerts as a normal call.

11.5.2 Call Forwarding All

A button set to this function switches your forwarding unconditional setting on/off.

11.5.3 Conference

A button set to this function starts a conference between your current call and any calls you already have on hold.

11.5.4 Do Not Disturb

A button set to this function turns your do not disturb setting on or off. The button icon is shown when do not disturb is on.

- When you are in 'do not disturb', your callers are redirected to voicemail if available or otherwise hear busy tone.
- People who call from numbers in your do not disturb exceptions list can still call you. Forwarding is set is applied to those calls.
- People who use a priority call function can also call you.
- Calls to any group of which you are a member are not presented to you (unless you are the last available member of the group).
- Enabling do not disturb will not affect any calls already being presented to your phone.
- You can still use the phone to make outgoing calls. When you go off-hook you will hear broken dial tone.

11.5.5 Hunt Group Night Service

A button set to this function turns the night service status of all the groups of which you are a member on or off. The button cannot be used to override a group automatically put into night service by a time profile on the telephone system.

11.5.6 Internal Auto Answer

A button set to this function switches your internal auto-answer setting on or off. When on, if the phone is idle, any internal call is automatically answered after three beeps. If the phone is in use, internal calls alert normally.

11.5.7 Last Number Redial

A button set to this function can be press to redial the number of the last outgoing call that you made.

You can redial the number of the last outgoing call that you made.

11.5.8 Page Group

A button set to this function starts the process of making a page call. After pressing the button, enter the extension number of the user or group that you want to page.

You can make a page call to another user or to the available members of a group. The users do not have to take any action to hear the page.

The phones called must support handsfree auto-answer in order to hear the page. If they do not, they do not receive any alerting call.

11.5.9 Priority Call

A button set to this function starts the process of making a priority call. After pressing the button, enter the user extension number that you want to call.

A priority call allows you to call another user even if they have 'do not disturb' set. The call will follow any forwarding and follow me settings they have in use but will not go to voicemail.

11.5.10 Ring Again

A button set to this function sets or clears a callback.

If you call another internal user and they do not answer, you can set a callback. When you have a callback set, the system will call you when the other user next uses ends a call. When you answer the callback, the system will automatically make another call to the user.

11.5.11 Speed Dial

A button set to this function allows you to dial any of your [personal speed dials](#) ^[21] or a [system speed dial](#) ^[21].

- To dial a system speed dial, press the button and then dial a 3-digit system speed dial number in the range 000 to 999.
- To dial a personal speed dial, press the button and then dial * followed by a 2-digit personal speed dial number in the range 00 to 99.

11.5.12 Speed Dial [nnnn]

A button [set to this function](#) ^[61] dials a stored number. That number can be any number composed of the digits 0 to 9 plus * and #. It can be an internal or an external number. It can be a partial number that you complete dialing after pressing the button. It can also be a [system short code](#) ^[12] for a telephone system feature. This button function is also known as Auto Dial and External Auto Dial.

11.5.13 Transfer

A button set to this function operates the same as dialing **Feature 70**.

11.5.14 User BLF

A button [set to this function](#) calls another user. The button is set to match another user's extension number, see [Internal Auto Dial](#) ^[61].

11.5.15 Voicemail

A button set to this function accesses your voicemail mailbox.

Chapter 12.

Glossary

12. Glossary

12.1 Abbreviated Ring

A single non-repeated ring. By default this is the type of ring used when another call alerts you when you already have a call in connected.

12.2 Appearance Button

Appearance buttons are used to represent calls made and received by you. They are configured by your system administrator. Normally your first 2 buttons are call appearance buttons but additional buttons can be configured as appearance buttons by the system administrator.

12.3 Attention Ring

Your system administrator can set what ringing should be used if another call alerts you when you already have a call connected. The options are a single non-repeated ring (abbreviated ring) or no ring.

12.4 Auto Hold

By default, when you have a connected call in progress, if you press another appearance button, the connected call is automatically put on hold. Without auto-hold, the connected call is ended when you press another appearance button.

12.5 Bridged Appearance Button

A bridged appearance button shows the state of one of another user's [call appearance](#) buttons. It can be used to answer or join calls on that other user's call appearance button. It can also be used to make a call that the call appearance user can then join or retrieve from hold.

- When the user's call appearance button alerts, your matching bridged appearance button also alerts. The bridged appearance button can be used to answer the call on the call appearance button user's behalf.
- When the call appearance button user answers or makes a call using that call appearance, your matching bridged appearance button show the status of that call, for example connected, on hold, etc. The bridged appearance button can be used to retrieve the call if on hold or to join the call if active.
- Bridged appearance buttons are not supported between users on different systems in a [Small Community Network](#).

12.6 Call Appearance Button

Call appearance buttons are used to represent calls to and from your phone. By having several call appearance buttons, you are able to answer and make several calls, switch between calls and perform other actions.

When all your call appearance buttons are in use, any further calls to your number follow your forward on busy setting if set or otherwise go to voicemail if available.

12.7 Call Coverage Button

Each call coverage button is associated with another user on your telephone system. The button allows you to be alerted when that user has an unanswered call still ringing. You can view the details of the call and answer it if required.

The settings of the user being covered control how long it rings at their phone before it also starts alerting on your call coverage button for that user. Call coverage appearance buttons are not supported between users on different systems in a Small Community Network.

12.8 Do Not Disturb

- When you are in 'do not disturb', your callers are redirected to voicemail if available or otherwise hear busy tone.
- People who call from numbers in your do not disturb exceptions list can still call you. Forwarding is set is applied to those calls.
- People who use a priority call function can also call you.
- Calls to any group of which you are a member are not presented to you (unless you are the last available member of the group).
- Enabling do not disturb will not affect any calls already being presented to your phone.
- You can still use the phone to make outgoing calls. When you go off-hook you will hear broken dial tone.

12.9 Do Not Disturb Exceptions

- These are numbers for caller's who can call you even when you are set to do not disturb. This only applies for calls to you. It does not apply for calls to a group of which you are a member.

12.10 Follow Me

Follow me to is used to redirect your calls to another extension where you will be working. The calls are presented with your user name so that they can be distinguished from calls for the extensions normal user. This allows you to share another person's phone without logging them off their phone.

The calls are still subject to all your user settings as if they were ringing at your phone. All calls are redirected.

12.11 Follow Me Here

Follow here is used to enable follow me at the extension to which you want your calls redirected.

12.12 Follow Me To

Follow me to is the function used to enable follow me from your own phone.

12.13 Forward on Busy

Forward on busy redirects your calls when your phone is not able to present you with any more alerting calls.

- By default this function is only applied to incoming external calls to you. However, if required internal calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward on busy/no answer destination. That number can be internal or external.
- Busy is defined as having no available call appearance buttons on which further calls can be presented.
- Group calls are not presented when you are busy and so are not forwarded by this setting.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

12.14 Forward on No Answer

Forward on no answer redirects calls that have alerted your phone but have not been answered for some reason.

- By default this function is only applied to incoming external calls to you. However if required internal calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward on busy/no answer destination. That number can be internal or external.
- No answer is defined as having been presented to your phone for your no answer time (default 15 seconds).
- Group calls are not forwarded.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

12.15 Forward Unconditional

Forward unconditional is used to immediately redirect your calls.

- By default this function is only applied to incoming external calls to you. However, if required internal calls and or group calls can also be selected.
- When enabled, all calls matching the settings are forwarded to the number set as the forward unconditional destination. That number can be internal or external.
- You can still use the phone to make outgoing calls. When you go off-hook you will hear broken dial tone.
- The forward on busy and forward on no answer options both use the same separate destination number. However if that number has not been set, they use the same destination as set for forward unconditional.

-
- If you have voicemail on, the telephone system will attempt to redirect forwarded calls to voicemail if they are still unanswered after having rung for your no answer time (default 15 seconds). This is not always possible for calls that have been forwarded to an external number.

12.16 Group

Your system administrator can include you as a member of a group or groups along with other users. Each group has its own extension number which is used to call the group.

When a call is presented to a group, it is presented to the available group members, either one at a time or all at the same time, until answered by one of the members.

How long a group call will ring at each group member's phone before being presented to the next member is controlled by the group's own settings. Groups also use voicemail and have their own settings for when an unanswered call should go to the group's mailbox. For group calls, the group's own voicemail settings are used rather than your settings.

12.17 Idle Line Preference

Having one of your phone's call or line appearance button set as the currently selected appearance button, means it will be the appearance button used when you go off hook. If this was not the case, you would need to select an appearance button before going off hook. Idle line preference automatically selects the first available call appearance or line appearance as your currently selected button when you do not have a call connected.

12.18 Internal Twinning

This method of twinning twins your phone (your primary phone) with another internal extension (your secondary phone). Both phones are yours and share the same extension number. Your incoming calls will ring on both phones. You can make your calls from either extension.

A typical example for internal twinning would be a user who uses both a normal desk phone and also needs a mobile phone while moving around the building.

Your settings are applied to both phones. If the secondary is a 1400, 1600, 9400, 9500, 9600, M-Series, T-Series phone, it will share the same call log and personal directory contacts as available on your primary. Similarly, message waiting indication for your mailbox is show on both phones.

12.19 Line Appearance Button

Line appearance buttons allow you to make and receive calls on a specific telephone line connected to your telephone system. The button also allows you to see when the line is in use by other users.

For incoming calls, the telephone system still determines the destination for the call. That may be a user or group. However, if you have a line appearance button for the line, you will see that there is a call alerting and can answer it if required.

- **Private Lines**

Special behaviour is applied to calls where the user has both a line appearance for the line involved and is also the Incoming Call Route destination of that call. Such calls will alert only on the Line Appearance button and not on any other buttons. These calls will also not follow any forwarding.

12.20 Logged Out

If you are logged out from any phone, you are treated as being busy to receiving any calls. Callers follow your forwarding settings if set or go to voicemail if available.

12.21 Login Code

You can use a login code to login at any phone on the telephone system and then use that phone as your own. It is also used to prevent access to some of your settings.

12.22 Missed Call

Missed calls are calls that ring at your phone but are not answered by you. Your 10 most recent missed calls are included in your call log.

The system administrator can configure whether missed calls should include calls that you did not answer but where answered for you by another user. For example by a user with a call coverage button set for your calls. If this mode is enabled, it will also include calls that were answered by your voicemail.

12.23 Missed Group Call

The system administrator can configure whether the telephone system should keep an internal log of missed group calls. They can then also set which groups of which you are a member, should have their missed calls shown as part of your missed calls call log. This does not require the group call to have been presented to you and missed.

12.24 Mobile Twinning

Mobile twinning is twinning where your calls ring at both your phone and at another number which can be an external number.

12.25 Park Call

Parking a call is similar to holding a call. However parked calls can be retrieved by other users on the telephone system.

A call that you park and leave parked for too long will recall to your phone. The recall will ignore any do not disturb and forwarding settings, recalling to the phone from which it was parked.

12.26 Park Slot Number

If you park a call without specifying a park slot number, the system automatically assigns a park number based on your extension number plus a single digit. For example, for extension 201, the first parked call uses park slot number 2010 if available. For the T7000, only the single automatic park slot of extension number plus 0 is used.

Call park buttons can be configured to match specific park slot numbers. A call parked using that button is given that park slot number. All users with a call park button set to the same number can see when there is a parked call there and can unpark that call using their button.

12.27 Ringing Line Preference

This setting is controlled by your system administrator and is normally on. When you are not connected to a call, if you receive an incoming call, ringing line preference will make the alerting appearance button your selected appearance button. You can answer the call by just lifting the handset without having to press the button to select it first.

Without ringing line preference, to answer the call on the alerting appearance button, you must press the appearance button to select it manually.

12.28 Short Codes

[Short codes](#)^[12] are numbers that you can dial from any types of phone on the telephone system. The following are default short codes that may be available on your system.

12.29 Small Community Network

Several IP Office telephone systems can be connected together to form a Small Community Network. You can then dial the user on other systems in the same way as for internal calls on your own system. The remote users are listed in the directory.

The system administrator can also configure which groups are accessible across the network. You may also be able to hot desk to a phone located on another system in the network.

12.30 System Administrator

The system administrator is able to make or arrange changes to the telephone system configuration. They are able to see and change most of your user settings.

12.31 System Phone User

Your system administrator can configure some user's as system phone users. They will be able to access a range of additional functions such as adding and deleting system directory entries.

12.32 Twinning

Twinning is a process whereby your calls ring on two phones. Twinning is only available if configured by the system administrator. There are two methods of twinning supported, [internal twinning](#)^[68] and [mobile twinning](#)^[69].

Chapter 13.

Document History

13. Document History

Date	Issue	Changes
14th March 2014	02c	<ul style="list-style-type: none">• Add details of Park & Page operation.

Index

A

Abbreviate Ring 66
 Abbreviated Dial Button 64
 Add
 to conference call 38
 Administrator 69
 Appearance Button
 Call Coverage 66
 Line Appearance 68
 Appearance Buttons 66
 Appearance Buttons
 Bridged Appearance 66
 Call Appearance 66
 Auto Answer 20
 Button 63
 Auto Dial
 Button program 61
 Auto Dial Button 64
 Auto Hold 66
 Automatic Intercom 20
 Button 63

B

Blind Transfer 29
 Bridged Appearance 66
 Broadcast 20, 64
 Answer 24
 broken dial tone 51, 54, 63, 66, 67
 Button
 Abbreviate Dial 64
 Auto Answer 63
 Auto Dial 64
 Automatic Intercom 63
 Call Forwarding All 63
 Callback 64
 Conference 63
 Dial Voice 63
 Do Not Disturb 63
 Feature Codes 62
 Forward All 63
 Forward Unconditional 63
 Functions 63
 Group Page 64
 Hunt Group Night Service 63
 Intercom 63
 Internal Auto Answer 63
 Last Number Redial 63
 Night Service 63
 No Calls 63
 Page 64
 Priority Call 64
 Program a feature 62
 Program Auto Dial 61
 Redial 63
 Ring Back 64
 Speed Dial 64
 Transfer 64
 User 64
 Voicemail 64

C

Call
 Answer a Page 24
 Auto Answer 20
 Automatic Intercom 20

Broadcast 20, 64
 Dial Direct 20
 Direct Voice 20
 Drop 29
 End 29
 Handsfree 29
 Headset 29
 Hold a Conference 39
 Intercom Dial 20
 Page 20, 64
 Page Direct 20
 Park 35
 Personal Speed Dial 21
 Pickup 25
 Priority Call 20, 64
 Release 29
 Ride 35
 Speed Dial 21
 System Speed Dial 21
 Transfer 29
 Unpark 35
 Volume 28
 Call Appearance Button 66
 Call Appearance
 Virtual 18
 Call Coverage Button 66
 Call Log
 Missed Calls 68
 Missed Group Calls 68
 Call Park ID 35, 69
 Call Pickup
 Direct 25
 Group 25
 Short Cde 12, 25
 Callback 19, 64
 Button 64
 When Free 63
 When Next User 63
 Calls
 Switch 28
 Code 25, 30, 35, 38, 42, 44, 49, 50, 51, 52, 53, 54, 69
 Conference
 Add call 38
 Button 63
 Hold 36, 38, 39
 Maximum Parties 38
 Music on hold 36, 38, 39
 Short Code 12, 38
 Transfer a Call 39

D

Dial Direct 20
 Dial tone
 Broken 51, 54, 63, 66, 67
 Dial Voice
 Button 63
 Dialing Code 25, 30, 35, 38, 42, 44, 49, 50, 51, 52, 53, 54, 69
 Direct Call Pickup 25
 Direct Voice 20
 Divert
 All 51, 67
 Busy 52, 67
 No Answer 53, 67
 Divert All
 Button 63
 Do Not Disturb 54, 63, 66

Do Not Disturb 54, 63, 66
Button 63
Exceptions 67
Priority Call 20, 64
Short Code 12, 54

Drop Call 29

E

End Call 29

F

Feature Codes

Button 62

Follow Me

Here 49, 67

Short Codes 12, 49

To 49, 67

Forward

All 51, 67

Busy 52, 67

Busy Short Code 12, 50, 52, 53

No Answer 53, 67

No Answer Short Code 12, 50, 52, 53

Unconditional 51, 67

Forward Unconditional

Button 63

Short Codes 12, 50, 51

G

Group 30, 68

Missed Calls 68

Night Service Button 63

Page Button 64

Short Code 12, 30

Group Call Pickup 25

Group Pickup

Short Code 12, 25

H

Handset

Volume 28

Handsfree 29

Hangup 29

Headset 29

Held call

Transfer 29, 36, 39

Hold

Auto Hold 66

Conference 36, 38, 39

Transfer 29, 36, 39

Hunt Group 30, 68

See Group 63

I

Idle Line Preference 68

Intercom

Button 63

Intercom Dial 20

Internal Auto Answer

Button 63

Internal twinning 69

L

Last Number Redial 19, 63

Last Number Redial

Button 63

Line Appearance 68

Line Preference

Idle Line Preference 68

Ringling 69

Login

Short Code 12, 44

Login Code 68

Logout

Short Code 12, 44

M

Mailbox 64

Short Codes 12, 42

Missed Calls 68

Group 68

Mobile twinning 55, 69

Music on hold 36, 38, 39

N

Network 69

Night Service 63

No Answer

Forward 53, 67

No Calls 54, 63, 66

Button 63

Exceptions 67

Priority Call 20, 64

P

Page 20, 64

Answer 24

Button 64

Direct 20

Park 35

Short Code 12, 35

Park Slot ID 35, 69

Pickup

Direct 25

Group 25

Short Code 12, 25

Priority Call 20, 64

Button 64

Program

Personal Speed Dial 21

Speed Dial 21

R

Redial 19, 63

Button 63

Release 29

Ride 35

Ring

Abbreviated 66

Attention Ring 66

Ring Again 19, 63, 64

Ring Back 19, 63, 64

Button 64

Ringer

Sound 58

Volume 58

Ringling Line Preference 69

S

SCN 69

Send All Calls 51, 67

Settings

Personal Speed Dial 21

Ringer Sound 58

Ringer Volume 58

Speed Dial 21

Short Code 25, 30, 35, 38, 42, 44, 49, 50, 51, 52, 53, 54, 69

Do Not Disturb 12, 54

Short Codes

- Conference 12, 38
 - Follow Me 12, 49
 - Forward on Busy 12, 50, 52, 53
 - Forward on No Answer 12, 50, 52, 53
 - Forward Unconditional 12, 50, 51
 - Group 12, 30
 - Login 12, 44
 - Logout 12, 44
 - Mailbox 12, 42
 - Park 12, 35
 - Pickup 12, 25
 - Unpark 12, 35
 - Voicemail 12, 42
- Slot Number 35, 69
- Small Community Network 69
- Sound 58
- Speaker 29
- Volume 28
- Speech
- Volume 28
- Speed Dial
- Personal 21
 - Program 21
 - System 21
- Speed Dial Button 64
- Supervised Transfer 29
- Switch Calls 28
- System
- Administrator 69
 - System Phone 69
- System Short Code 25, 30, 35, 38, 42, 44, 49, 50, 51, 52, 53, 54, 69

T

- Transfer 29, 64
- Held call 29, 36, 39
 - Using a Conference 39
- Twining 69
- Internal Twining 55, 68
 - Mobile Twining 55, 69

U

- Unpark 35
- Short Code 12, 35
- Unsupervised Transfer 29
- User Button 64

V

- Virtual Call Appearances 18
- Voicemail 64
- Short Codes 12, 42
- Volume
- Call 28
 - Ringer 58

Performance figures and data quoted in this document are typical, and must be specifically confirmed in writing by Avaya before they become applicable to any particular order or contract. The company reserves the right to make alterations or amendments to the detailed specifications at its discretion. The publication of information in this document does not imply freedom from patent or other protective rights of Avaya or others.

All trademarks identified by the ® or ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners.

This document contains proprietary information of Avaya and is not to be disclosed or used except in accordance with applicable agreements.

© 2014 Avaya Inc. All rights reserved.